# **Aboistop** vibrant

Product name: Aboistop vibrant Product model: D157010 Operating voltage: 3.7V Batter v capacity: 300mAh Rated input: DC 5V / 1A Waterproof rating: IP67

Operating temperature: -10°C~+50°C Storage temperature: -20°C~+60°C Device volume : 70mm\*37mm\*40mm

Net weight: 71a

# FC CE (RHS) A CO








## First Time Using

- The default setting of this product is: sensitivity sensor level 6, vibration level 3
- Fully charge the battery before using the first time. In standby mode, touch the button M to view the charge level (more details please see page 9 Battery Power)
- Tip

Please read the user manual carefully before use and register it in a safe place!



- Product wearing time is recommended no more than 12 hours/day.
- For pets ranging from 5kg-50kg (11lbs~110lbs) and neck circumference up to 62cm (25in). Not suitable for dogs less than 5kg (11lbs) or younger than 6
- Children should not play with this product. Keep it away from children.



## Wearing







Adjust the length of the strap to fit the pet's neck

## Wearing Points







**USB** Charging

Cable

Bark Training Device User Manual

USB Charging Cable

Nylon Collar

Bark Training Device

& Nylon Collar

- 2 -

User Manual

- 7 -

Contents

## Circumference

and battery level.

Power ON & OFF

(M)

View

Loop

to turn ON

to turn OFF

Functions & Displays

0 is off

Bark sensor

sensitive

\* Must enter setting mode for turn OFF.

Vibration setting.


7 is highest vibration. - -

7 is most - - - - - -

\* Short press to toggle through and view these settings

See Page 9 for instructions to enter setting mode.

### Bark Collar Components



Checking

Switch Mode



/ Adjust Leve



**User Operation** 

---- With (#: 🖫 🏵 ) 🙌

. - - - - - - - - .

Π~7 »\$»

1~7 S

Introduction

---- With ( 🗑 🐵 ),



## **User Operation**


## Functions Setting Process

















Sleeping

Training

Mode

Beep

Vibration

Sound

Trigger

Mode

2 Working Modes

Automatically exit setting mode after 3 secs

# Settings are set.





Introduction

No barking for 5 secs.

Dog is barking, training

Always exists and cannot

0~7 level output settings.

0 is off. Default is level 3.

sleep mode begins.

mode activated.

be cancelled.

No level setting.

# Display goes away.



\* If the battery indicator is 1, please use product after

shuts down, ---- Display

Increase

Sensitivity

Automatically

If the product is abnormal during use,

Make Sure

Tight

Enough

after prompt flashes

**User Operation** 

## Training Mode

Battery Power

fully charged.

Troubleshooting

you can do the following:

Training





\* If the vibration is off, there will be no corresponding display.

## Single Method Execution Order




- 5 -

\* This means that sound, and vibration do not happen simultaneously during barking. First, your dog will hear the sound, then vibration will occur.


# ABOISTOP VIBRANT

## **USER MANUAL** D157010



## **How Does the Device Work?**

## Training Methods Combination



\* For protection, there is a 1 minute pause after 7 triggers, regardless if the dog is still barking

- 6 -

Trigger Methods

2 Basic Training Methods

1~7 level sensitivity.

Default setting is 6.